



**40771 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 29 | 29 | 42 |

- > Finish shown: Pewter (PW)
- > Base ø18 mm



**40773 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 35 | 35 | 46 |

- > Finish shown: Brushed Nickel (BN)
- > Base ø29 mm



**51444 ALUMINUM KNOB**

| l  | w  | h  |
|----|----|----|
| 25 | 25 | 35 |
| 30 | 30 | 40 |
| 35 | 35 | 47 |

- > Finish shown: Brushed Nickel (BN)



**40157 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 39 | 39 | 35 |

- > Finish shown: Antique English (AEBK)
- > Knob ø33 mm



**40760 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 32 | 32 | 29 |
| 38 | 38 | 34 |

- > Finish shown: Brushed Nickel (BN)



**40749 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 39 | 39 | 37 |

- > Finish shown: Brushed Nickel (BN)
- > Knob: 36 (ø) X 34 (h) mm
- > With backplate



**40267 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 42 | 42 | 40 |

- > Finish shown: Venetian Bronze (VB)
- > Knob ø31 mm
- > Non-solid type



**40654 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 43 | 43 | 25 |

- > Finish shown: Brushed Nickel (BN)
- > Knob ø31 mm



**40735 ZINC KNOB**

| l  | w  | h  |
|----|----|----|
| 50 | 50 | 27 |

- > Finish shown: RAW
- > Knob: 30 (ø) X 25 (h) mm
- > With backplate
- > Non-solid type

Note: Dimensions in mm unless stated otherwise